

HIGH DENSITY MELAMINE RESIN COATED PARTICLE BOARD

For cubicle systems Noxx TR, type D-Bravo, Basic type D, Bambino type D

Kemmlit UK

Bays Platt, Skirmett, Henley-on-Thames, Oxfordshire RG9 6TD United Kingdom

Tel: +44(0)1491 638606 Fax: +44(0)1491 638072

www.kemmlituk.com info@kemmlituk.com

High density melamine resin coated particle board panels are usually easy to clean. Only non-aggressive cleaning agents should be used. Sometimes special cleaning agents must be used, which may be acidic or flammable or contain solvents. In this case please adhere to the appropriate accident prevention and precaution instructions and also make sure to ventilate the rooms sufficiently.

I. REGULAR CLEANING:

Please only use non-abrasive cleaning agents. The cubicles can be wiped with a moist cloth, and should be wiped with a dry cloth afterwards.

III. ATTENTION:

The following agents must not be used: scrubbing and grinding agents (scouring powder, steel wool), polishing agents, wax, bleaching agents, cleaning agents containing strong acids, e.g. decalcifier with formic acid and amino-sulpho-acid, drain pipe cleaner, hydrochloric cleaner and cleaning agents for silverware.

II. HEAVY STAINING:

1. staining

Extreme staining of the particle board panels such as ball-point pen or felt pens can be removed with pure nitro, diluted nitro or spirit. Please wipe the surface with a moist cloth and wipe it dry afterwards. The ABS lipping must not come into contact with the above mentioned cleaning agents. Please clean the ABS lipping with non-abrasive general household cleaning agents.